



Cod. OL022328238

Rotondo Piano cm 32
Round Platter cm 32



Cod. OL02232823A

Rotondo Piano cm 32
Round Platter cm 32



Cod. AC001238238

Piatto Fondo cm 23
Soup Plate cm 23



Cod. AC020D38238

Ovale Piano Cm 36X28
Oval Plate Cm 36X28



Cod. AC004158238

Coppetta cm 15Xh7
Fruit Bowl cm 15xh7



Cod. AC015088238

Tazza Caffè s/p cc 90
Coffee Cup cc 90



Cod. AC032108238

Lattiera cc 105
Creamer cc 105



Cod. AC032258238

Lattiera cc 270
Creamer cc 270



Cod.AC022408238

Rotondo Piano cm 30
Round Platter cm 30



Cod.AC000278238

Piatto Piano cm 27
Dinner Plate cm 27



Cod. AC002218238

Piatto Dessert cm 21
Dessert Plate cm 21



Cod.AC003158238

Piatto Pane cm 16
Bread Plate cm 16



Cod. AC020D68238

Ovale Piano Cm 26X20
Oval Plate Cm 26X20



Cod. AC020D98238

Ovale Piano Cm 30X24
Oval Plate Cm 30X24



Cod. AC024188238

Insalatiera cm 18xh7
Salad Bowl cm 18xh7



Cod. AC024248238

Insalatiera cm 24xh9
Salad Bowl cm 24xh9



CCod. AC016228238

Tazza The s/p cc 250
Tea Cup cc 250



Cod. AC005128238

Piattino Caffè cm 12
Coffee Saucer cm 12



Cod. AC006158238

Piattino The cm 15
Tea Saucer cm 15



Cod. AC033038238

Teiera cc 330
Tea Pot cc 330