



Cod. AC000278239

Piatto Piano cm 27
Dinner Plate cm 27



Cod. AC020D38239

Ovale Piano Cm 36X28
Oval Plate Cm 36X28



Cod. AC004158239

Coppetta cm 15Xh7
Fruit Bowl cm 15xh7



Cod. AC032108239

Lattiera cc 105
Creamer cc 105



Cod.AC001238239

Piatto Fondo cm 23
Soup Plate cm 23



Cod.AC002218239

Piatto Dessert cm 21
Dessert Plate cm



Cod. AC003158239

Piatto Pane cm 16
Bread Plate cm 16



Cod.AC022408239

Rotondo Piano cm 30
Round Platter cm 30



Cod. AC020D68239

Ovale Piano Cm 26X20
Oval Plate Cm 26X20



Cod. AC020D98239

Ovale Piano Cm 30X24
Oval Plate Cm 30X24



Cod. AC024188239

Insalatiera cm 18xh7
Salad Bowl cm 18xh7



Cod. AC024248239

Insalatiera cm 24xh9
Salad Bowl cm 24xh9



CCod. AC005128239

Piattino Caffè' cm 12
Coffee Saucer cm 12



Cod. AC006158239

Piattino The cm 15
Tea Saucer cm 15



Cod. AC015088239

Tazza Caffè' S/P cc 90
Coffee Cup cc 90



Cod. AC016228239

Tazza The S/P cc 250
Tea Cup cc 250



Cod. AC032258239

Lattiera cc 270
Creamer cc 270



Cod. AC033038239

Teiera cc 330
Tea Pot cc 330



Cod. OI022328239

Rotondo Piano cm 32
Round Platter cm 32



Cod. OL02232823C

Rotondo Piano cm 32
Round Platter cm 32