



Cod. AL000240000

Piatto Piano cm 24xh4
Dinner Plate cm 24xh4



Cod. AL001240000

Piatto Fondo cm 24xh4
Soup Plate cm 24xh4



Cod. AL020740000

Ovale Piano cm 32x21xh4
Oval Plate cm 32x21xh4



Cod. AL020730000

Ovale Piano cm 29x19xh4
Oval Plate cm 29x19xh4



Cod. AL020710000

Ovale Piano cm 23x16xh3
Oval Plate cm 23x16xh3



Cod. AL015110000

Tazza Caffè senza piatto cc 80
Coffee Cup cc 80



Cod. AL011190000

Tazza The con piatto cc 200
Tea Cup & Saucer cc 200



Cod. AL017270000

Tazza Colazione senza piatto cc 340
Breakfast Cup cc 340



Cod. AL002200000

Piatto Dessert cm 20xh4
Dessert Plate cm 20xh4



Cod. AL022450000

Rotondo Piano cm 45xh5
Round Platter cm 45xh5



Cod. AL020760000

Ovale Piano cm 38x25xh5
Oval Plate cm 38x25xh5



Cod. AL020750000

Ovale Piano cm 35x23xh5
Oval Plate cm 35x23xh5



Cod. AL020720000

Ovale Piano cm 25x17xh4
Oval Plate cm 25x17xh4



Cod. AL022400000

Rotondo Piano cm 41xh5
Round Platter cm 41xh5



Cod. AL022350000

Rotondo Piano cm 36xh4
Round platter cm 36xh4



Cod. AL020770000

Ovale Piano cm 42x29xh6
Oval Plate cm 42x29xh6



Cod. AL005140000

Piattino Caffè cm 12xh2
Coffee Saucer cm 12xh2



Cod. AL010110000

Tazza Caffè con piatto cc 80
Coffee Cup & Saucer cc 80



Cod. AL016190000

Tazza The senza piatto cc 200
Coffee Cup cc 200



Cod. AL006140000

Piattino The cm 14xh2
Tea Saucer cm 14xh2



Cod. AL007170000

Piattino Colazione cm 16xh2
Breakfast Saucer cm 16xh2



Cod. AL012270000

Tazza Colazione con piatto cc 340
Breakfast Cup & Saucer cc 340