



**Cod. FO000271705**

Piatto Piano cm 27  
Dinner Plate cm 27



**Cod. FO001201705**

Piatto Fondo cm 20  
Soup Plate cm 20



**Cod. FO000271706**

Piatto Piano cm 27  
Dinner Plate cm 27



**Cod. FO001201706**

Piatto Fondo cm 20  
Soup Plate cm 20



**Cod. FO000271707**

Piatto Piano cm 27  
Dinner Plate cm 27



**Cod. FO001201707**

Piatto Fondo cm 20  
Soup Plate cm 20



**Cod. FO000271709**

Piatto Piano cm 27  
Dinner Plate cm 27



**Cod. FO001201709**

Piatto Fondo cm 20  
Soup Plate cm 20



**Cod. FO002211705**

Piatto Dessert cm 21  
*Dessert Plate cm 21*



**Cod. FO024251705**

Insalatiera cm 25  
*Salad Bowl cm 25*



**Cod. FO010111705**

Tazza Caffè con Piatto cc 95  
*Coffee Cup&Saucer cc 95*



**Cod. FO011211705**

Tazza The con Piatto cc 210  
*Tea Cup&Saucer cc 210*



**Cod. FO002211706**

Piatto Dessert cm 21  
*Dessert Plate cm 21*



**Cod. FO024251706**

Insalatiera cm 25  
*Salad Bowl cm 25*



**Cod. FO010111706**

Tazza Caffè con Piatto cc 95  
*Coffee Cup&Saucer cc 95*



**Cod. FO011211706**

Tazza The con Piatto cc 210  
*Tea Cup&Saucer cc 210*



**Cod. FO002211707**

Piatto Dessert cm 21  
*Dessert Plate cm 21*



**Cod. FO024251707**

Insalatiera cm 25  
*Salad Bowl cm 25*



**Cod. FO010111707**

Tazza Caffè con Piatto cc 95  
*Coffee Cup&Saucer cc 95*



**Cod. FO011211707**

Tazza The con Piatto cc 210  
*Tea Cup&Saucer cc 210*



**Cod. FO002211709**

Piatto Dessert cm 21  
*Dessert Plate cm 21*



**Cod. FO024251709**

Insalatiera cm 25  
*Salad Bowl cm 25*



**Cod. FO010111709**

Tazza Caffè con Piatto cc 95  
*Coffee Cup&Saucer cc 95*



**Cod. FO011211709**

Tazza The con Piatto cc 210  
*Tea Cup&Saucer cc 210*