





Cod. AC022400000

Piatto Rotondo cm 30
Round Platter cm 30



Cod. AC000270000

Piatto Piano cm 27
Dinner Plate cm 27



Cod. AC000250000

Piatto Piano cm 25
Dinner Plate cm 25



Cod. AC002210000

Piatto Dessert cm 21
Dessert Plate cm 21



Cod. AC003150000

Piatto Pane cm 16
Bread Plate cm 16



Cod. AC001230000

Piatto Fondo cm 23
Soup Plate cm 23



Cod. AC004150000

Coppetta cm 15x6
Fruit Bowl cm 15x6



Cod. AC004130000

Coppetta cm 13x6
Fruit Bowl cm 13x6



Cod. AC004110000

Coppetta Rettangolare cm 11x7x4
Rectangular Fruit Bowl cm 11x7x4



Cod. AC024240000

Insalatiera cm 24x9
Salad Bowl cm 24x9



Cod. AC024210000

Insalatiera cm 22x8
Salad Bowl cm 22x8



Cod. AC024180000

Insalatiera cm 18x7
Salad Bowl cm 18x7



Cod. AC020D80000

Ovale Piano cm 39x30
Oval Plate cm 39x30



Cod. AC020D30000

Ovale Piano cm 37x28
Oval Plate cm 37x28



Cod. AC020D90000

Ovale Piano cm 30x24
Oval Plate cm 30x24



Cod. AC020D60000

Ovale Piano cm 26x20
Oval Plate cm 26x20



Cod. AC005120000

Piattino Caffè cm. 12
Coffee Saucer cm. 12



Cod. AC006150000

Piattino The cm. 15
Tea Saucer cm. 15



Cod. AC007160000

Piattino Colazione cm. 16
Breakfast Saucer cm. 16



Cod. AC015180000

Tazza Caffè senza piatto cc. 185
Coffee Cup cc. 185



Cod. AC015080000

Tazza Caffè senza piatto cc. 90
Coffee Cup cc. 90



Cod. AC010180000

Tazza Caffè con piatto cc. 185
Coffee Cup & Saucer cc. 185



Cod. AC010080000

Tazza Caffè con piatto cc. 90
Coffee Cup & Saucer cc. 90



Cod. AC016220000

Tazza The senza piatto cc. 250
Tea Cup cc. 250



Cod. AC011220000

Tazza The con piatto cc. 250
Tea Cup & Saucer cc. 250



Cod. AC017300000

Tazza Colazione senza piatto cc. 325
Breakfast Cup cc. 325



Cod. AC012300000

Tazza Colazione con piatto cc. 325
Breakfast Cup & Saucer cc. 325



Cod. AC018300000

Tazza Brodo senza piatto cc. 325
Soup Cup cc. 325



Cod. AC013300000

Tazza Brodo con piatto cc. 325
Soup Cup & Saucer cc. 325



Cod. AC017360000

Tazzone Mug cc. 375
Mug cc. 375



Cod. AC032500000

Lattiera cc. 565
Creamer cc. 565



Cod. AC032250000

Lattiera cc. 270
Creamer cc. 270



Cod. AC032100000

Lattiera cc. 105
Creamer cc. 105



Cod. AC032050000

Lattiera cc. 55
Creamer cc. 55



Cod. AC030060000

Caffettiera cc. 640
Coffee Pot cc. 640



Cod. AC033030000

Theiera cc. 330
Tea Pot cc. 330



Cod. AC06630000

Corpo Zuccheriera cc. 325
Sugar Bowl without lid cc. 325



Cod. AC0AD210000

Porta Stuzzicadenti cm 5xh5
Toothpick Holder cm 5xh5



Cod. AC0SL080000

Spargisale cc. 80
Salt Shaker cc. 80



Cod. AC0SB080000

Spargispepe cc. 80
Pepper Shaker cc. 80



Cod. AC0SA080000

Set Sale e Pepe cc. 80
Salt & Pepper 2 pcs cc. 80



Cod. AC0VA120000

Vaso Fiori cc. 140xh12
Vase cc. 140xh12



Cod. AC0PS110000

Posacenere cm 11xh4
Ash Tray cm 11xh4



Dec. 8070



Dec. 8214



Dec. 8217