





Cod. OV022310000

Rotondo Piano cm 31
Round Platter cm 31



Cod. OV000270000

Piatto Piano cm 27
Dinner Platter cm 27



Cod. OV001230000

Piatto Fondo cm 23
Soup Plate cm 23



Cod. OV002190000

Piatto Dessert cm 19
Dessert Plate cm 19



Cod. OV003160000

Piatto Pane cm 16
Bread Plate cm 16



Cod. OV001200000

Fondina cm 20
Soup Plate cm 20



Cod. OV008180000

Piattino Brodo cm 18
Soup Saucer cm 18



Cod. OV018360000

Tazza Brodo S/P cc 360
Soup Cup cc 360



Cod. OV004160000

Coppetta cm 15
Fruit Bowl cm 15



Cod. OV020370000

Ovale Piano cm 32
Oval Plate cm 32



Cod. OV020320000

Ovale Piano cm 32
Oval Plate cm 32



Cod. OV020260000

Ovale Piano cm 26
Oval Plate cm 26



Cod. OV024200000

Insalatiera cm 20
Salad Bowl cm 20



Cod. OV024260000

Insalatiera cm 26
Salad Bowl cm 26



Cod. OV006150000

Piattino The cm 15
Tea Saucer cm 15



Cod. OV005120000

Piattino Caffè' cm 12
Coffee Saucer cm 12



Cod. OV016210000

Tazza The S/P cc 210
Tea Cup cc 210



Cod. OV015080000

Tazza Caffè' S/P cc 80
Coffee Cup cc 80



Cod. OV032230000

Lattiera cc 230
Creamer cc 230



Cod. OV032150000

Lattiera cc 120
Creamer cc 120



Cod. OV033650000

Theiera cc 600
Tea Pot cc 600



Cod. OV033370000

Theiera cc 350
Tea Pot cc 350



Cod. OV066220000

Zuccheriera S/C/ Bolo cm10
Sugar Bowl (No Lid) cm 10



Cod. OV069C10000

Coperchio Zuccheriera
Sugar Bowl Lid

