





Cod. TH322320000

Rotondo Piano cm 32
Round Platter cm 32



Cod. TH300280000

Piatto Piano cm 28
Round Platter cm 28



Cod. TH300260000

Piatto Piano cm 26
Round Platter cm 26



Cod. TH301240000

Piatto Fondo cm 24
Soup Plate cm 24



Cod. TH302210000

Piatto Dessert cm 21
Dessert Plate cm 21



Cod. TH303170000

Piatto Pane cm 17
Bread Plate cm 17



Cod. TH304140000

Coppetta cm 14
Fruit Bowl cm 14



Cod. TH304100000

Coppetta cm 10
Fruit Bowl cm 10



Cod. TH324250000

Insalatiera cm 25
Salad Bowl cm 25



Cod. TH324200000

Insalatiera cm 20
Salad Bowl cm 20



Cod. TH323320000

Pasta Bowl cm 32



Cod. TH320420000

Ovale Piano cm 42x27
Oval Plate cm 42x27



Cod. TH320360000

Ovale Piano cm 36x24
Oval Plate cm 36x24



Cod. TH320320000

Ovale Piano cm 32x23
Oval Plate cm 32x23



Cod. TH320290000

Ovale Piano cm 29x19
Oval Plate cm 29x19



Cod. TH320220000

Ovale Piano cm 22x9
Oval Plate cm 22x9



Cod. TH325260000

Salsiera cm 19x8x 9h
Sauce Bowl cm 19x8x9h



Cod. TH334320000

Mezzaluna cm 32x27
Half moon cm 32x27



Cod. SC315100000

Tazza caffè senza piatto cc 110
Coffee cup cc 110



Cod. SC305130000

Piattino caffè Ø cm. 13
Coffee saucer Ø cm. 13



Cod. SC310100000

Tazza caffè con piatto cc 110
Coffee cup & saucer cc 110



Cod. SC316210000

Tazza Thè senza piatto cc 210
Tea cup cc 210



Cod. SC306160000

Piattino Thè Ø cm. 16
Tea saucer Ø cm. 16



Cod. SC311210000

Tazza Thè con piatto cc 210
Tea cup & saucer cc 210



Cod. TH332500000

Lattiera cc 650
Creamer cc 650



Cod. TH332250000

Lattiera cc 250
Creamer cc 250



Cod. TH332100000

Lattiera cc 140
Creamer cc 140



Cod. TH333050000

Theiera cc 550
Tea Pot cc 550



Cod. TH333030000

Theiera cc 360
Tea Pot cc 360



Cod. TH331250000

Zuccheriera cc 200
Sugar Bowl cc 200



Dec. 8206

