



Times  
Square



**Cod.TS000260000**

Piatto Piano cm 26x26  
*Dinner Platter cm 26x26*



**Cod.TS000260047**

Piatto Piano cm 26x26  
*Dinner Platter cm 26x26*



**Cod.TS000260779**

Piatto Piano cm 26x26  
*Dinner Platter cm 26x26*



**Cod.TS000264746**

Piatto Piano cm 26x26  
*Dinner Platter cm 26x26*



**Cod.TS002200000**

Piatto Dessert cm 20x20  
*Dessert Plate cm 20x20*



**Cod.TS002200047**

Piatto Dessert cm 20x20  
*Dessert Plate cm 20x20*



**Cod.TS002200779**

Piatto Dessert cm 20x20  
*Dessert Plate cm 20x20*



**Cod.TS002204746**

Piatto Dessert cm 20x20  
*Dessert Plate cm 20x20*



**Cod.TS001210000**

Piatto Fondo cm 21x21  
*Soup Plate cm 21x21*



**Cod.TS024230000**

Insalatiera cm 23x23  
*Salad Bowl cm 23x23*



**Cod.TS010090000**

Tazza Caffè C/P cc 90  
*Coffee Cup&Saucer cc 90*



**Cod.TS011170000**

Tazza The con Piatto cc 170  
*Tea Cup&Saucer cc 170*